


BATLEXP



G350

Instructions

System Startup and Shutdown

1. TF1/INT is system card. After inserting system card, long press power button on right side to start system. If system software is functioning correctly after startup, motor will vibrate.
2. Shutdown: Press SELECT to turn off device. Software Shutdown (Safety Protection System):
3. TF2/EXT is for reading games with format of FAT 32 and can copy required Roms on the computer.

Main System Interface

After entering main system interface, please refer to following table for button operations:

Left&Right D-pad and joystick	Switch Emulator Platform
A Button	Enter or Confirm
B Button	Back or Cancel
START Button	Settings
SELECT Button	Soft Reboot or Soft Shutdown Settings
L2R2	Flip Game Menu Pages
Long Press X Button	Game Favorites



Emulator Operation

Retroarch		PS	
Menu	Menu	Menu	Open emulator menu
Menu+ Up/Down	Adjust volume	Menu+ START	Exit
Menu+ Left/Right	Select save state		
Menu+ Y	Screenshot	NDS	
Menu+ A	Pause	L2	Switch Horizontal or Vertical Screen
Menu+ L1	Load State	R2	Switch Single or Dual Screen
Menu+ R1	Save State	Menu	Emulator Menu
Menu+ L2	Display Frame Rate	Menu+ START	Exit
Menu+ R2	Fast Forward		
Menu+ L3	Back		
Menu + START	Quit		

Standalone Emulator

For PS , NDS games, press M + START to exit game.

Buttons and Ports



Key Settings

After entering system, press START button to access settings.

1. SYSTEM-SETTINGS -> LANGUAGE

Language Settings
System Settings -> Language

2. Brightness Settings

System Settings -> Brightness

3. External Controller Settings

After connecting a controller to USB-OTG interface, press A key on controller to enter controller button settings.

Charging Function

5V2A Charging Function

standard package includes a 2-line TYPE-C charging cable (can only be used for 5V2A charging and cannot be used for data transmission).

Inserted charging cable, the game console will enter charging mode. Yellow LED light on when charging or fully charged, Green LED light on when operating normally, Red light ling on when battery is low.

Copying Games

First Method

Insert the game memory card into the computer and use DiskGenius software:

1. Open DiskGenius and ensure it recognizes the memory card.
2. Format the TF card to FAT32.
3. Create a corresponding ROM folder for the emulator (e.g., gba) (note: use lowercase).
4. Once the transfer is complete, safely eject the card.

Second Method

If using the memory card provided with the game console, you can copy games by inserting it into a card reader connected to a Windows 10 computer.

Q&A

Q: I can't install games using DiskGenius.

A: Please make sure no other software is occupying the memory card, which may prevent the installation.

Q: How to favorite games for easy access?

A: Long press the X button on the game you like to favorite it, and view it in the FAVORITES section.

Q: There are too many emulators, and it's inconvenient to browse.

A: Press B on the home screen to bring up the simplified list menu for easier browsing.

Q: I don't know how to exit the game when playing.

A: While a game is running, press M+START to force quit the game.

Precautions

Please do not press the reset button while reading data, as it may cause data loss.