


正面


背面

R36H MANUAL

RGB 20S Instruction



Functional description



Combination Key Description

Brightness Adjustment--R3 + UP/DOWN	Exit Game -----SELECT + START
Save/Read Game -----SELECT + L1/R1	Enter ESTROARCH-----SELECT + X/L3 + R3
Restart the game-----SELECT + B	Pause the game -----SELECT + A
Save Location -----SELECT + UP/DOWN	

Special Instruction

power on/off & memory card description

1. You must insert the system card into TF1-OS position before starting up, then press the power key to power on and enter the system.
2. Insert the copied game data card into the TF2-GAME bit, after booting into the system, select(OPTIONS-ADVANCED-SWITCH TO SD2 FOR ROMS), and display the content of the game card after running.

Warning instructions

Without a system card,the device will only turn on yellow light without picture Display. At this time, you must insert the system card and press the reset key To enter the system.

If the software sets SD2 and pulls out TF2-GAME and turns on, it will also appear that the system does not wake.

Charging instructions

1. When the host red light flashes, please charge in time. After connecting DC to charge, the indicator shows static red.
2. If the red light starts flashing and does not charge in time, the host will be powered off automatically after about an hour of service. Please press the power key for 12 seconds until the green light is turned off and recharged. After about an hour. It will turn on normally. So please charge it in time.

Classical parameter

64bit Four core Cortex-A7 1.5GHz CPU	5V 2A Fast charging	Trigger structure new feel	3.5 inches 640*480 HD screen	Dual TF card Supports max 256 GB	10+ Emulators
--	------------------------	-------------------------------	------------------------------------	-------------------------------------	------------------

Configuration List

Video game handheld	+1
Type-c data line	+1
Certificate	+1
Product description	+1

正反面折叠，折叠尺寸：100*80mm
80g铜版纸单色印刷